



Common Messages For Radio Bridge Sensors

VERSION 1.3
DECEMBER 2018

TABLE OF CONTENTS

1. QUICK START	2
2. OVERVIEW	2
2.1. Common Messages Overview	2
2.2. Revision History	2
2.3. Document Conventions	2
3. COMMON MESSAGE PROTOCOL	3
3.1. Uplink Messages	3
3.1.1. Reset Message 0x00	4
3.1.2. Supervisory Message 0x01	5
3.1.3. Tamper Message 0x02	6
3.1.4. Rate Limit Exceeded Message 0xfc	6
3.1.5. Test Message 0xfd	7
3.2. Downlink Messages	7
3.2.1. Downlink Ack	9
3.2.2. Rate Limit Configuration Downlink 0xfc	10
4. APPENDIX A: SENSOR TYPE CODES	11
5. TRADEMARKS AND COPYRIGHT	12
6. DISCLAIMERS, WARRANTY, AND CUSTOMER SUPPORT	12
6.1. Disclaimers	12
6.2. Warranty	12
6.3. Customer Support	12

1. QUICK START

To start using your sensor, simply go to:

<https://console.radiobridge.com>

From here you can register your device and immediately start receiving messages from the sensor.

The sensor configuration, message monitoring, and setting up alerts is usually self-explanatory through the user interface. For further explanations of any features common to all wireless sensors, you may refer to this user guide.

2. OVERVIEW

2.1. Common Messages Overview

The wireless sensors designed and manufactured by Radio Bridge provide full sensor to cloud solutions for Internet of Things (IoT) applications. This document describes the messages common to all wireless sensors. For messages specific to each sensor, please refer to the corresponding user guide.

2.2. Revision History



Table 1 Revision History

Revision	Date	Description
1.0	April 2018	Initial release of the document
1.1	November 2018	Global downlink config definitions
1.2	December 2018	Supervisory period configuration
1.3	December 2018	Fixed byte definitions for supervisory message

2.3. Document Conventions

Table 2 Document Conventions

Font / Icon	Meaning

	Important notes
	Warnings and cautions

3. COMMON MESSAGE PROTOCOL

This section defines the protocol and message definitions common to all wireless sensors. Common messages include basic error messages, tamper, supervisory, and downlink acknowledgements but do not include sensor specific data.

3.1. Uplink Messages

The uplink messages (sensor to web application) have the structure defined in the following table.

Table 3 Message Structure for Wireless Sensors

Protocol Version	Packet Count	Message Type	Message Payload
4 bits	4 bits	1 byte	0-7 bytes

The Protocol Version (currently a constant 1) is used to provide extensibility to the specific format of a Message Type. It is not expected there will be more than 1 format for each Message Type.

The Sequence Number starts at 0 for the first message sent from the Sensor to the Cloud. It is incremented by 1 for each subsequent message. When it reaches 0xF (15 decimal), it wraps back to 0. Its purpose is to help identify when a Message is lost. For example, if the Sequence Number goes from 2 to 4, instead of 3, this would indicate that a Message has been lost. (It can also help identify out-of-order or duplicate Messages, although this should be much less likely.)

The Message Type byte format is 8 bits where all combinations (256 different Message Types) are possible; although for a given Sensor, there are generally much fewer Message Types. There are two kinds of Message Types, those that are Common to all Sensors, and those that are Unique to a specific sensor. The Common Message Types are described in this document, while the Unique Message Types are described in each individual sensor document

Each Message Type has between 0 and 8 bytes of payload data that is specific to the sensor. The common message types are defined in the following table.

Table 4 Common Message Types for Wireless Sensors

Message	Payload	Description
0x00	5-byte reset code	Device has Reset. The cause of reset is represented in the 5-byte reset code payload.
0x01	3-byte status	Daily Supervisory message (1-2 per day). The 3-byte payload contains status (current) of the sensor. See the Supervisor section for detail on the payload.
0x02	1-byte event	A Tamper event has occurred. This includes enclosure or wall mount tampers. See the tamper section for detail on the tamper payload.
(see datasheets)	Sensor event	Sensor events are defined in their individual datasheets
0xfc	Current rate limit	Rate limit exceeded. See the Rate Limit section for more detail.
0xfd	Sensor state	Test message with current sensor state
0xfe		Reserved
0xff	1-byte status	Downlink message ack. See the Downlink section for more detail.

3.1.1. Reset Message 0x00

The Reset Message is sent to the Cloud every time that the Sensor is Reset. The Reset Code has to do with the nature of the reset and is used by the factory for diagnostic purposes.

The reset message payload is defined in the following table.

Table 5 Reset Payload

Bytes	Description
0	Sensor type code

1	Hardware version
2-3	Firmware version
4-5	Reset code (used for factory diagnostics)

The sensor type codes are enumerated in Appendix A.

3.1.2. Supervisory Message 0x01

The wireless sensors will send a periodic supervisory message so that a backend system can verify that the device is still alive and to report error conditions. The supervisory message also contains a payload that contains the status (current) of the sensor.

The supervisory message payload is defined in the following table.

Table 6 Supervisory Payload

Bytes	Description
0	Supervisory error codes
1	Sensor state
2	Battery level

The bit definitions of the supervisory error codes are shown in the following table.

Table 7 Supervisory Error Code Bit Definitions

Bits	Description
7:5	Not used
4	Tamper detected since last reset
3	Current tamper state
2	Error with last downlink
1	Battery Low (under 2.8V)

0	Radio Comm Error. Communication with the integrated radio has failed and device has been reset.
---	---

The current sensor state (byte 1 of the supervisory message) is defined by the individual data sheets.

The battery level (byte 2 of the supervisory message) is a two-digit battery voltage. For example, if the battery voltage is 2.9V, byte 2 would be 0x29.

3.1.3. Tamper Message 0x02

The sensor will send a message when the tamper switch has been either opened or closed through either an enclosure tamper or a wall mount tamper. The tamper message contains a 1-byte payload as shown in the following table.

Table 8 Tamper Payload

Payload	Description
0x00	Tamper switch opened
0x01	Tamper switch closed



Not all sensors support the tamper feature. See the individual datasheets for more information.

3.1.4. Rate Limit Exceeded Message 0xfc

The sensors have a rate limiting feature as a protection mechanism to ensure the sensors do not flood the wireless network with messages. This may happen if a particular configuration, environment, or a combination thereof creates an unexpected scenario where event messages are generated continuously.

The default rate limit is 100 and is measured between supervisory messages. In other words, if more than 100 event messages are sent between two supervisory messages (18 hours apart), the sensor will send the 0xfc message and will not send new events until the next supervisory event.

The rate limiter is configurable through the 0xfc downlink command, and if it is set to 0 then rate limiting is disabled. The maximum value of the rate limit is 0xfe (0xff is reserved).

3.1.5. Test Message 0xfd

The test message is initiated when a magnet is applied to the side of the sensor (see user guides for support on individual sensors). When the magnetic reed switch is tripped, a test message 0xfd is sent with the current state of the sensor. This can be used to test connectivity in a particular area or used to calibrate sensors that require specific thresholds.

3.2. Downlink Messages

A downlink message is one that is sent to the sensor from the cloud and is used to configure the sensor itself. Messages cannot be initiated from the cloud since the sensor is typically sleeping and the radio is turned off, so the sensor itself must initiate a downlink message. The supervisory, reset, and tamper-open (not tamper close) messages all request a downlink message as a response, and the response must be received within 30 seconds of the request.

The messages that can be sent back to the sensor upon a downlink request are shown in the following table.

Table 9 Downlink Messages

Command	Payload	Description
0x00	Not used	Not used
0x01	3 bytes	General configuration
(see datasheets)	0-7 bytes	Sensor configuration, see individual datasheets
0xfc	1 byte	Rate limit

The general configuration command is used for configuration parameters that apply to all sensor types. This command is defined in the following table.

Table 10 General Configuration Command 0x01

Byte	Description
0x00	Disable sensor events
0x01	Radio config
0x02	Supervisory period. Default 19 hours.

The Disable sensor events byte is defined in the following table.

Table 11 Disable Sensor Events Bit Definitions

Bit	Description
7:1	Not used
0	Disable all sensor events

When the sensor events are disabled (bit 0 in the above table), supervisory and tamper-open will still initiate messages but the sensor events will not. Setting bit 0 (set to 1) will disable new event messages and clearing bit 0 (set to 0) will re-enable the event messages.

The Radio config byte is defined in the following table.

Table 12 Radio Config Bit Definitions

Bit	Description
7:1	Not used
0	Enable Adaptive Data Rate (LoRaWAN only). Set to enable ADR, clear to disable ADR. Default is 0. Available in firmware v1.4 and above.

Note that the adaptive data rate control described in the above table is **only available in firmware version 1.4 or later**.

The supervisory period from the general configuration command controls the time between supervisory messages as defined in the following table.

Table 13 Supervisory Period Bit Definitions

Bit 7	Bits 6:0
0	Period defined in hours (1-127 hours). Available in firmware v1.4 and above.
1	Period defined in minutes (1-127 minutes) Available in firmware v1.4 and above.

For example, to receive a report every 4 hours, byte 1 would be set to 0x04. To receive a periodic report every 15 minutes, byte 1 would be set to 0x8f.



Some features described above such as the Enable Adaptive Data Rate and Supervisory Period are **only available in firmware version 1.4 or later**. The firmware version is supplied in the sensor's reset message and is displayed on the Radio Bridge Console

3.2.1. Downlink Ack

The sensor will reply to the downlink data with a 0xFF message (downlink ack) with a payload shown in the following table.

Table 14 Downlink Ack Messages

Command	Payload
0x00	Not used
0x01	Message was invalid or undefined
0x02	Message was valid

This downlink ack message is used by the cloud app to verify that the downlink message was received by the sensor and that it was considered valid.

3.2.2. Rate Limit Configuration Downlink 0xfc

The sensors have a rate limiting feature as a protection mechanism to ensure the sensors do not flood the wireless network with messages (see the section Rate Limit Exceeded Message 0xfc).

The rate limit, as in the number of messages allowed between supervisory messages, is configurable through the 0xfc downlink command. The payload is one byte with a range of 0-255 and the default is 100. If the rate limit is set to 0, rate limiting is disabled.



Disabling the rate limiter may cause unrecoverable failures in the field.

4. APPENDIX A: SENSOR TYPE CODES

The sensor type codes in the table below are provided as product identifiers and sent as part of the reset message.

Table 15 Sensor Type Codes

Sensor	Code
Door/Window	0x01
Door/Window High Security	0x02
Contact	0x03
Temperature No-Probe	0x04
Temperature External Probe	0x05
Single Push Button	0x06
Dual Push Button	0x07
Acceleration-Based Movement	0x08
Tilt	0x09
Water	0x0a
Tank Level Float	0x0b
Glass Break	0x0c
Ambient Light	0x0d
Air Temperature and Humidity	0x0e

5. TRADEMARKS AND COPYRIGHT

Radio Bridge™, SubGig®, and BridgeBee® are trademarks of Radio Bridge Inc in the United States.

© 2018 Radio Bridge Inc. All rights reserved.

6. DISCLAIMERS, WARRANTY, AND CUSTOMER SUPPORT

6.1. Disclaimers

Information in this document is subject to change without notice and does not represent a commitment on the part of Radio Bridge. Radio Bridge provides this document “as is,” without warranty of any kind, expressed or implied, including, but not limited to, the implied warranties of fitness or merchantability for a particular purpose. Radio Bridge may make improvements and/or changes in this manual or in the product(s) and/or the software described in this manual at any time.

6.2. Warranty

To view product warranty information, go to the following website: www.radiobridge.com

6.3. Customer Support

Radio Bridge offers free technical support at:

www.radiobridge.com/forums

Radio Bridge also offers technical support plans and service packages to help our customers get the most out of their Radio Bridge products.

For information on Technical Support plans and pricing, visit us at www.radiobridge.com.